

Easier Plotting Versus Output Power

This example shows using the X_SWP schematic control block to easily plot any nonlinear measurement vs. output power. [Test drive the example](#)

Your browser does not support HTML5 video.