

Understanding AWR .emz Files

AWR Design environment.emz files are an archive all the dependencies needed in your design including some or all of the following:

- .emp files
- .vin files (stores window locations)
- data sets
- PDK model

Creating .emz files

You can create an .emz file from the **File > Archive Project** menu command.

Opening .emz files

You can open .emz files the same way you can open .emp files including:

- Double clicking on the file.
- Drag and drop the file over the AWRDE.
- Use the **File > Open Project** menu and in the dialog that opens, change the type to be **Project Archive (*.emz)**