

Remove Space from Schematic Names

To run this script

Select **Scripts > Schematic > Remove_Space_from_Schematic_Names** from the Menus.

Or, in versions that support the script, you can run the utility directly from this page using this button.

Description

This script will replace spaces in schematic names loaded in the project with underscores. Some processes on computers are not tolerant of spaces in filenames, such as exporting layouts, etc. This script will automate removing any spaces in schematic names.