


Problem accessing AWR license across WAN

The default timeout for FLEXlm v8.4a or newer is only 100000 microseconds. If the client cannot connect to the server within this time period, the application returns a "-15" error and exits.

You can avoid timing out by increasing the timeout value to **2147483647** microseconds. To increase the connection timeout from the client machine, add (or edit) the following environment variable as follows.



The image shows a Windows-style dialog box titled "New System Variable". It has a blue header bar with a close button (X) in the top right corner. The dialog contains two text input fields. The first field is labeled "Variable name:" and contains the text "FLEXLM_TIMEOUT". The second field is labeled "Variable value:" and contains the text "2147483647". Below the input fields, there are four buttons: "Browse Directory...", "Browse File...", "OK", and "Cancel". The "OK" button is highlighted with a blue border. In the bottom right corner, there is a small icon of a person.