


Easily Edit Graph Axis Limits and Steps

In the AWRDE V14 release, you could easily update graph titles, [Easily Edit Graph Titles](#).


Starting in V15, this capability is extended to graph axis limits and minor axis steps.

For example, see the rectangular graph below.




Double-click directly over the graph y-axis minimum value, **-40** in this case.

A text edit box will display around the value and the cursor will be inserted where you clicked.




When you are done editing, type **Enter** or click outside the text edit box to complete the edit operation. Notice the y-axis minimum value is now changed, in this example changed to **-30**.




The same edits can be done for the maximum value of the axis as well as settings for the x-axis.

To change the grid step, edit the first value after the minimum to indicate the desired step size.

For example, from the above graph, if the value -25 is double clicked as shown below.



When this value is changed to -28, the graph will change the y-axis grid spacing to be 2 dB as shown below.



You can reset the axis settings easily by right-clicking over any area on the graph and selecting **Restore Axis Settings**.

