

# Emulating Standard Cadence Bindkeys in AWR

## Problem

How to emulate Cadence bindkeys in AWR environment?

## Solution

Open the example [Analog\\_Office\\_Configure.emp](#) which is in the AWR install and follow the instruction given in the design notes to run the script to match Cadence default settings for hotkeys and colors.